
Wärmemengenzähler-Set waagerecht
Heat Meter Set, horizontal
Montageanleitung/Assembly instruction



Das Roth Wärmemengenzähler Einbauset waagerecht kann mit dem Roth Heizkreisverteiler Universal oder mit Durchflussanzeige eingesetzt werden.

Das Wärmemengenzähler-Set wird wie oben abgebildet montiert:

Der Volumenmesser wird in der Rücklauf-Leitung zum Heizkreisverteiler (**A**) montiert.

Der direkt eintauchender Temperaturfühler mit M10x1 Gewinde wird in die Fühleraufnahme des Kugelhahns (**B**) im Vorlauf montiert.

Montageraum: 250 mm x 268 mm.
Wichtig: UP-Verteilerschrank auf min. 120 mm ausziehen, Abmessung Wärmemengenzähler beachten.

The “Roth Heat Meter Set, horizontal” can be deployed in combination with a Roth Universal heating circuit manifold or Roth manifold with flow meter.

The Heat Meter Set is mounted shown on the picture above:

The volume meter is positioned in the return of the manifold (**A**).

Installing the temperature sensor M10x1 with direct contact to the liquid, using ball valve (**B**) in supply.

Assembly area: 250 mm x 268 mm.
The front of the manifold cabinet should be pulled out to min.120 mm, please observe the heat meter dimension.

12. Januar 2021 · 04 · Technische Änderungen vorbehalten.

ROTH WERKE GMBH · Am Seerain 2 · 35232 Dautphetal · Telefon 06466/922-0 · service@roth-werke.de · www.roth-werke.de